




www.monsieurmousse.ca

## TRIPOD STAND MODEL

Open the tripod stand to its maximum, then tighten the clamping ring. Insert the safety pin into the first hole. To prevent any risk of instability, do not extend the upper mast. Install the machine on its tripod stand.



Use the GFCI device on the side of the barrel to turn on the machine and the pump simultaneously. (Make sure the machine switch located under the carrying handle is in the "ON" position).

Wait until the machine reaches full speed before opening the flow valve. The foam will spurt out after a few seconds.

Caution: to prevent water from flowing back into the engine, the fan must always run at full speed before sending the fluid into the foam machine.

To turn off, close the flow valve first, then use the GFCI device on the side of the barrel to turn off the machine and the pump simultaneously.

When finished, please, rinse the equipment before returning it (the tripod stand, the water pump and the barrel).

\* Water from a well could affect the quantity and quality of the foam produced.

-Avoid a build-up of foam at the rear air inlet of the machine.

 $\bigcirc$ 

-Keep away from the rear area of the machine any objects that could be sucked up by the fan.

-Do not run around the foam machine.

-Adult supervision is required.

-Be careful not to get water on the electrical connections to prevent any risk of electric shock.



Monsieur Mousse inc. 169 Park row, Mascouche, Qc. 7L 3M5 450 477-7796 info@monsieurmousse.ca

S